

This device complies with Part 15 of the FCC and Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from to which the


receiver is connected. — Consult the dealer or an experienced radio/TV technician for help.


Important note: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.





All brand names shown are trademarks of their respective owners.


DOC ID 2008 Rev 01











ye K WARNING RISK OF FIRE RISK OF ELECTRICAL SHOCK RISK OF BURNS CONTROLLING APPLIANCES CONTROLLING APPLIANCES CAUTION: TO REDUCE THE RISK OF OVERHEATING AND POSSIBLE DAMAGE TO OTHER EQUIPMENT, DO NOT INSTALL TO CONTROL A RECEPTACLE, A MOTOR-OPERATED APPLIANCE, A FLUORESCENT LIGHTING FIXTURE OR A TRANSFORMER-SUPPLIED APPLIANCE. \square \square Β Add-On switche ONLY USE TO CONTROL INCANDESCENT OR DIMMABLE CFL/LED BULBS DO NOT EXCEED RATINGS • DO NOT USE TO CONTROL ANY DEVICE WHERE UNINTENDED OPERATION COULD CAUSE UNSAFE CONDITIONS (HEAT LAMP SUN LAMP FTC.) FOR INDOOR USE ONLY Plua-in In-Wall Add-on Switches Smart Dimmers In-Wall Plug-in Smart Switches Smart Switches - 4

MANUA

0

0

clare™

ClareVue

In-wall Dimmer

Smart control

Multiple paddle

colors available

In-Wall

Smart Dimmers

In-Wall Motion

Switch or Dimmer

Enbrighten

Smart LED Bulb

CVL-IWD-10

NOT FOR USE WITH MEDICAL OR LIFE-SUPPORT EQUIPMENT Z-WAVE ENABLED DEVICES SHOULD NEVER BE USED TO SUPPLY POWER TO OR CONTROL THE ON/OFF STATUS OF MEDICAL OR LIFE-SUPPORT EQUIPMENT.

SPECIFICATIONS ZW3010 Power: 120VAC, 60Hz Signal (frequency): 908.4/916MHz Maximum loads: 600W, 2-gang 500W or 3-gang 400W incandescent, 300W dimmable CFL/LED Range: Up to 150ft. line of sight between the wireless controller and the closest Z-Wave receiver module Operating temperature range: 32-104° F (0-40° C)

Type 1 enclosure, independently mounted (vertical position only), operating control: type 1.c action, pollution degree (2), impulse voltage (2500V), software class A For indoor use only Specifications subject to change without notice due to continuing product improvement

Clare Controls offers a two (2) year limited warranty on original Clare Controls components, from the date

of shipment from Clare Controls. To view complete limited warranty details, including limitations and

exclusions, visit www.clarecontrols.com/warranty



The fixture controlled by the Z-Wave In-Wall Smart Dimmer must not exceed 600W incandescent; 300W dimmable CFL/LED. The dimmer is designed only for use with permanently installed fixtures.


Getting to know your new Z-Wave device

- Turn ON/OFF and adjust dim levels manually or remotely via the Z-Wave controller
- Can be added in multiple groups and scenes
- May be used in single-pole installation or with up to five Clare-Branded Add-on Switches in 3-way or 4-way wiring configuration
- Compatible with all incandescent and most dimmable CFL/LED bulbs Auto line/load detection
- Interchangeable paddle switch white & light almond paddle in package • Uses a standard, decorative-style wallplate for single-gang installations (wallplate not included)


• Blue LED indicates switch location in a dark room

- Z-Wave certified for simple pairing and integrated home automation
- Screw terminal installation requires wiring connections for line (hot), load, neutral and ground. Traveler wire required for 3-way or 4-way installation
- This Z-Wave device has advanced features that allow you to customize your experience. These features can only be adjusted by a Z-Wave enabled controller that supports the Z-Wave configuration command class.





A. Ground (Green/Bare) B. Line or Load (Black) C. Line or Load (Black) D. Traveler (Red/Other) E. Neutral (White)



0

 (\mathbf{F})

G

¥۵)

F. Top rocker — Press to turn dimmer ON, press & hold increases brightness

G. Bottom rocker – Press to turn dimmer OFF, press & hold to dim


 $\widehat{}$

4.

Adding your device to a Z-Wave network

- 1. Follow the instructions for your Z-Wave certified controller to add a device to the Z-Wave network 2. Once the controller is ready to add your device, press the
- top or bottom of the wireless smart dimmer (rocker). Now you have complete control to turn your fixture ON/OFF according to groups, scenes, schedules and interactive
- automations programmed by your controller. If your Z-Wave certified controller features remote access, you can control your fixture from your mobile devices. If prompted by the controller to enter the S2 security code, refer to the OR code/security number on the side of the box or the QR code label on the product (see Figure 1). Enter the 5-digit code.





To remove and reset the device

1. Follow the instructions for your Z-Wave certified controller

1. Quickly press ON (top) button three times, then immediately

press the OFF (bottom) button three times. The LED will

flash ON/OFF five times when completed successfully.

Note: This should only be used if your network's primary

to remove a device from the Z-Wave network 2. Once the controller is ready to remove your device, press the top or bottom of the wireless smart dimmer (rocker).

To return your switch to factory defaults

controller is missing or otherwise inoperable

Hinge Pin

Smart Door Sensor

Outdoor Smart

WARNING – SHOCK HAZARD

In-Wall

Smart Fan Control

11

11

In-Wall

 \mathbb{O}

Turn OFF the power to the branch circuit for the switch and lighting fixture at the service panel. All wiring connections must be made with the POWER OFF to avoid personal injury and/or damage to the switch. This device is intended for installation in accordance with the National Electric Code and local regulations in the United States or the Canadian Electrical Code and local regulations in Canada. If you are unsure or uncomfortable about performing this installation consult a qualified electrician.

Multi-switch wiring

For 3-way installations, please refer to Clare-branded Add-on Switch manual


Single-switch wiring

Before installation, you may wish to change the paddle color to match your wallplate or décor. Please proceed to section 5.

1. Shut off power to the circuit at circuit breaker or fuse box.

IMPORTANT! Verify power is OFF to switch box before continuing. 2. Remove wallplate.

- 3. Remove the switch mounting screws.
- 4. Carefully remove the switch from the switch box. DO NOT disconnect the wires.
- There are up to five screw terminals on the switch: these are marked: A. GROUND — Green/Bare
- B. LINE OR LOAD Black (connected to power or lighting) C. LINE OR LOAD — Black (connected to power or lighting)



- D. TRAVELER Red/Other (only in 3-way installations) E. NEUTRAL - White
- Match these screw terminals to the wires connected to the existing switch. 5. Disconnect the wires from the existing switch. Label wires according to the previous
- terminal connection

Observe important wiring information

IMPORTANT! This switch is rated for and intended to only be used with copper wire.


Wire gauge requirements

Use 14AWG or larger wires suitable for at least 80° C for supplying line (hot), load, neutral, ground and traveler connections.

Wire strip length

For attachment using the enclosure's holes, strip insulation 5/8in. (16mm).

- UL specifies the tightening torque for the screws is 14Kgf-cm (12lbf-in).
- 1. Connect the green or bare copper ground wire to the GROUND terminal.
- 2. Connect the black wire from the light to either LINE/LOAD terminal.
- 3. Connect the black wire from the electrical service panel (hot) to either LINE/LOAD terminal.
- 4. Connect the white wire to the NEUTRAL terminal (use a jumper wire if needed).
- Note: The traveler terminal is only used for 3-way or 4-way wiring and should remain insulated if the dimmer is being installed in a 2-way system (one switch & one load). 5. Insert dimmer into the switch box being careful not to pinch or crush wires.
- 6. Dimmer must be independently mounted (vertical position only).
- 7. Secure the dimmer to the box using the supplied screws.





8. Mount the wallplate.

9. Reapply power to the circuit at fuse box or circuit breaker and test the system.

Basic operation

- The connected light can be turned ON/OFF and adjust dim levels in two ways:
- 1. Manually from the front panel of the dimmer.
- 2. Remotely with a Z-Wave controller.

Manual control


- The front panel rocker dimmer allows the user to turn ON/OFF the connected fixture.
- 1. To turn the connected fixture ON, press the top of the rocker.
- 2. To turn the connected fixture OFF, press the bottom of the rocker.

Adjust dim levels

- 1. To increase brightness, press and hold the top of the rocker.
- 2. To decrease brightness, press and hold the bottom of the rocker.

Cvcle LED light

- The LED below the dimmer acts as a guide light or status indicator.
- How to cycle through options: Press up three times and down once quickly.
- 1. LED is ON when the load is off (guide light in the dark) (default).
- 2. LED is ON when the load is ON (indicates the dimmer is ON).
- 3. LED is always OFF.
- 4. LED is always ON (illuminates dimmer in the dark).



To change color of the paddle

This step is optional. Before installation, you may want to change the color of the paddle

- to match your wallplate or décor. 1. Lift the air gap tab at the base of the paddle.
- 2. Push side tabs in on one side and then the other to release paddle. Lift the cover up and off.
- 3. Simply put the new paddle onto the switch by inserting the air gap and side tabs

and snapping securely into place. Once this step has been completed,

please return to section 3.

or 4-way installations. Connecting the traveler terminal of this switch to a standard, non-Clare-branded switch will cause damage or result in improper function. If this switch is a part of a 3-way or 4-way multi-switch installation, do not connect the traveler wire or apply power until **Clare**-branded Add-on Switches are correctly installed. For more information on 3-way or 4-way installations, view the manual or quick start guide with the Clare-branded Add-on

The Clare-branded Add-on Switch is

required for multi-switch 3-way

This device supports association command class (3 Groups)

- Association Group 1 supports Lifeline, Multi-level Switch report DOC ID 2008 Association Group 2 supports Basic Set and is controlled with the local load Association Group 3 supports Basic Set and is controlled by double pressing the ON or OFF button
- Each Association Group supports 5 total nodes

NOTE: Actual performance of any CFL or LED will vary from bulb type to bulb type and among different manufacturers. It is important to note only bulbs designed as dimmable should be used on a dimmer. To find out if your bulb is dimmable, please check the package, the bulb itself or call the bulb manufacturer directly.

WAVE

Z-WAVE INTEROPERABILITY

This product can be added and operated in any Z-Wave network with other Z-Wave certified devices from other manufacturers and/or other applications. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase reliability of the network.

0.

1

