

User's Manual



Elite Max **COMMERCIAL POOL HEAT PUMP**




Table of contents

Foreword	5
A. Safety Precautions	1
1. Warning	1
2. Attention	2
3. Safety	2
B. About your heat pump	3
1. Transportation	3
2. Accessories:	3
3. Operating condition and range:	4
4. Introduction of different modes:	4
5. Technical parameter	5
6. Dimension	6
C. Installation guidance	7
1. Installation reminder	7
2. Wiring requirements	9
3. Electric wiring Diagram	11
4. Installation options	12
D. Operation guidance	17
1. Key Function	17
2. Operation Instruction	18
E. Testing	20
F. Commissioning	22
F. Maintenance	23
G. Trouble shooting for common faults	24
H. Electrical wiring schematic	27
Water Testing Pump Output	28
External input	28
I. Wi-Fi operation	29
Product Warranty Registration	39

Foreword

Thank you for choosing the Madimack high efficiency inverter pool heat pump.

All our heat pumps are built and designed to the highest standard and are protected by our extended warranty service for peace of mind.

Warranty registration is required to be submitted online in conjunction with the commissioning page and warranty registration page in the Appendix section at the back of the booklet

www.madimack.com.au/warranty-registration

Please read and fully understand all information provided before attempting to install the pool heat pump.

For technical questions and further information please contact
support@madimack.com.au

We hope you enjoy using our heat pumps.

Thank you!

A. Safety Precautions

We have provided important safety messages in this manual for the installation, maintenance and repair of your heater.
Please read thoroughly and obey all safety messages.

1. Warning



The WARNING sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury or injury to a third party. These signs are rare, but are extremely important.

	a. Keep the heat pump away from fire source.
	b. Unit must be placed in a well-ventilated area; indoor or enclosed areas are not allowed.
	c. Repair and disposal must be carried out by trained service personnel
	d. Vacuum the system completely before welding. Welding should only be carried out by professional trained personnel.

2. Attention

- a. Please read the following instructions before installation, use and maintenance.
- b. Installation, must be completed only by competent persons only, and in accordance with this manual.
- c. Check all water connections are sealed and tested before operating the heat pump
- d. Except for the methods recommended by the manufacturer, do not use any methods to accelerate the defrosting process or clean the frosted parts.
- e. If a repair is required, please contact the nearest after-sales service center. The repair process must be strictly in accordance with this manual. Repairs made by unauthorized persons may void the warranty.
- f. Correctly set temperature required for personal preference making sure to avoid overheating or overcooling.
- g. Please do not stack substances or other materials which may block the air flows to the inlet or outlet areas. This causes the efficiency of the heater to be reduced, and may damage the machine.
- h. Do not use or stock combustible gas or liquids such as thinners, paint and fuel, to avoid fire!
- i. In order to optimize the heating effect, please install heat preservation insulation on pipes between swimming pool and the heater, and please use a recommended cover on the swimming pool.
- j. Connecting pipes of the swimming pool and the heater should be less than 10m.


3. Safety

- a. Please keep the main power supply out of reach from the children.
- b. If power is suddenly disconnected during operation, and later the power is restored, the heater will start up automatically.
- c. Please switch off the main power supply in high storm weather to prevent the machine from damage that could be caused by lightning strikes.
- d. Any repairs should be carried out in a well-ventilated area. Any source of ignition is prohibited during the inspection.
- e. Safety inspections must be carried before the maintenance or repair for heat pumps with R32 gas in order to minimize the risk.


B. About your heat pump

1. Transportation


- a. Always keep upright




- b. Loosen the screws in the bottom, and use a forklift to transport.



- c. Do not lift by the water unions, otherwise, the titanium heat exchanger inside the heat pump may be damaged)



2. Accessories:





3. Operating condition and range:

To provide you comfort and pleasure, please set swimming pool water temperature efficiently and economically.

The heat pump can work between air $-10^{\circ}\text{C} \sim 43^{\circ}\text{C}$, and its ideal operation range is between air $15^{\circ}\text{C} \sim 25^{\circ}\text{C}$.

4. Introduction of different modes:

- a. The heat pump has two modes: Boost and Silent.
- b. They have different strengths under different conditions.

Mode	Modes	Strength
	Boost mode	Heating capacity: 20% to 100% capacity Intelligent optimization Fast heating
	Silent mode	Heating capacity: 20% to 80% capacity Sound level: 3dB (A) lower than Boost mode

5. Technical parameter


Model	EM60	EM110
PERFORMANCE CONDITION: Air 27°C/ Water 27°C/ Humid. 80%		
Heating capacity (kW)	60.2	115.0
Average COP at 50% Speed	10.5	10
PERFORMANCE CONDITION: Air 15°C/ Water 26°C/ Humid. 70%		
Heating capacity (kW)	40.1	80.8
Average COP at 50% Speed	7	7
TECHNICAL SPECIFICATIONS		
Advised pool volume (m ³) *	125~260	250~520
Operating air temperature (°C)	-10°C~43°C	
Fan direction	Vertical	
Power supply	400V/3Ph/50Hz	
Rated input power (kW)	2.26~8.90	4.68~17.5
Rated input current (A)	3.27~12.9	6.78~25.3
Max input current (A)	20	40
Sound level at 10m dB(A)	33.0~41.0	35.0~44.0
Advised water flux (m ³ /h)	20~25	40~50
Water connection (mm)	65	100
Net dimension LxWxH (mm)	1000x1110x1260	2100x1090x1280
Net Weight (kg)	212	459

Remarks:


This heat pump is able to perform normal within air temp -10°C~43°C, efficiency will not be guaranteed out of this range. Please take into consideration that the pool heater performance and parameters are different under various conditions.

Related parameters are subject to adjustment periodically for technical improvement without further notice. For details please refer to nameplate.

6. Dimension



Size (mm) / Name / Model	A	B	C	D	E	F	G	H
EM60	1000	660	1110	1070	1000	780	105	1260



Size (mm) / Name / Model	A	B	C	D	E	F	G	H
EM110	1000	1630	1090	1050	2100	515	140	1280

C. Installation guidance

1. Installation reminder

Only competent persons are authorized to install the heat pump and should be educated with the relevant building codes and standards of their current state or local governing body for all electrical, mechanical and water services to prevent danger or damage to the unit.


a. Location and water pipe connection



The inverter pool heat pump must be installed in a well-ventilated place.

b. Typical installation diagram

Installations can differ dependent on site conditions below is only a representation of one possibility. Note: the inlet and outlet positions for the pipework is a representation only and can be positioned differently



Plumbing connection installation guide


2. Placing the unit and water connections

a. Placing the unit and fixing

- The frame must be fixed by bolts (M10) to a concrete foundation or brackets. The concrete foundation must be solid and fastened; the bracket must be strong enough and anti-rust treated.
- Do not stack substances that will block air flow near the inlet or outlet area, and there should be no obstruction within 50cm behind the machine. Suffocation of air reduces the efficiency of the heater and could damage the unit.
- The machine may need an additional pump (not supplied). The recommended pump must adhere to the specification-flux of the machine, please refer to the technical parameters.

b. Water connections

- The inlet and outlet water unions should not be installed with soft flexible pipes. The heat pump **must** be connected with rigid pipes!




Electrical connection installation guide

2. Wiring requirements


- a. Connect the heat pump to an appropriate power supply, the voltage should comply with the rated voltage of the product.
- b. The machine **must** be earthed
- c. Wiring must be handled by a professional technician according to the circuit diagram.
- d. Install electrical protection device according to local code for wiring
- e. The layout of power cable and signal cable should be orderly and not affecting each other.

Step 1. opening the maintenance panel


- ① Remove three screws outside




- ② Open the panel



- ③ Remove two screws inside




- ④ Open the internal




Step 2. Power cord must be passed through below 3 holes


- ① Connect the wire through three holes




- ② Restore the internal panel




- ③ Fix the internal panel by two screws



- ④ Restore the panel





- ⑤ Fix the panel by three screws



3. Electric wiring Diagram

For power supply: 400V 50Hz



- Note: 1)  Must be hard wired, plug is not allowed.
2) The swimming pool heat pump must be earthed

Current protection devices must be installed in accordance with local electrical regulations


Please see appendix for further wiring information including pump control and auxiliary input

4. Installation options

6. Installation options

- **Flow switch activated heating**


The heat pump is activated by the flow of water initiated from the filtration/circulation pump, if the heater gets to temperature within the timers the unit will first start to use the inverter technology to slow the machine down to maintain the temperature and eventually to a stop.



1. Chlorinator controller initiates the filtration pump.
2. Heat pump's flow switch senses the water flowing through the heat pump.
3. Heat pump starts and will run until temperature is reached or filtration pump switches off
4. No additional internal wiring to the heat pump is required in this set up
5. No additional settings needed to be changed
6. If circulation pump is not running and no flow is detected unit will display E3 – this is normal and an indication the unit is sitting idle waiting for the filtration pump to start again.
7. If the pool temperature is not reached within the filtration times you may need to extend the timers to match the heating requirement.

- **Heat pump activation without using the chlorinator controller and using the one pump used for filtration (additional controller required)**


An on-board pump output relay can activate the main filtration pump by using it in combination with a “single pump controller” without using the chlorinator timers needing to be activated which will stop over chlorination but still use a single supply pipework for the pool. This set-up is best when only single pipework is available from pool and doesn't have individual heating pipework. Efficient with only one pump working.



- 1- Termination points are labelled P1-P2 from the on-board relay and is activated by the timers and pool temperature, and will continue to run the pump until the heated water reaches the set temperature or the timer switches off.
- 2- Once temperature is reached or the timer is finished the heat pump will switch off the relay output stopping the circulation pump.
- 3- If the pool reaches temperature but the timer is still active the heat pump will switch off relay to stop the circulation pump. Whilst the timer is still active every hour it will run the circulation pump for 2 minutes to test the water temperature. If the temperature is 1 degree below set point the heat pump will continue to run the circulation pump and start the heating process again.
- 4- P1 – P2 relay up to 10A output for circulation pump (check total load on circuit when combined) (P1 and P2 is an output relay switch NOT active neutral terminals, please see wiring diagram for further information.)
- 5- Heat Pump timers are set through the mobile application and required a Wi-Fi connection. If no Wi-Fi is present then additional external timer may be required (sold separately)
- 6- On the single pump controller, connect the black power cable to a 240V GPO, connect the piggyback cord into the chlorinator, and plug the pump into the bottom of the controller.
- 7- Connect the Fig 8 wire from the single pump controller to the P1-P2 terminals. (See single pump controller manual for more information)
- 8- Adjust parameter “P6” to 100 as per section E

- **Individual circulation pump installation.**


An onboard output initiates the circulation pump to start and stop from the heat pump itself based on temperature and timers. For use when there are dedicated heating pipes and to separate from the filtration timers.



- 1- Termination points are labelled P1-P2 from the on-board relay and is activated by the timers and pool temperature, and will continue to run the pump until the heated water reaches the set temperature or the timer switches off.
- 2- Once temperature is reached or the timer is finished the heat pump will switch off the relay output stopping the circulation pump.
- 3- If the pool reaches temperature but the timer is still active the heat pump will switch off relay to stop the circulation pump. Whilst the timer is still active every hour it will run the circulation pump for 2 minutes to test the water temperature. If the temperature is 1 degree below set point the heat pump will continue to run the circulation pump and start the heating process again.
- 4- P1 – P2 relay up to 10A output for circulation pump (check total load on circuit when combined) (P1 and P2 is an output relay switch not active neutral terminals, please see wiring diagram for further information).
- 5- Heat Pump timers are set through the mobile application and required a WiFi connection. If no WiFi is present then additional external timer may be required (sold separately)
- 6- It is recommended to install a power point for the pump to plug into for any future service work to the pump which may be required.
- 7- Circulation pump should be sized accordingly to suit the site conditions and flow required.
- 8- Adjust parameter “P6” to 100 as per section E

- **Solar retro**

In some situations, when a heat pump is replacing a solar heating system, the pipework is available to be used next to the house but there is no way of adding a new electrical circuit to the pool equipment. With the use of an additional temperature sensor you can use the in-built flow switch to activate the heating. Allowing you to use the existing solar pump and to install the heater closer to the switch board.



- 1- It may be impractical to get a new power cable from the house switch board to the pool equipment area due to finished flooring etc, in this case It may be possible to use the existing pipework which connects to the house and install a power cable from there.
- 2- An external thermostat controller can initiate the existing circulation pump, thus running the heat pump through the flow switch for full temperature control.
Please speak to your installer for more information.
- 3- No additional wiring to the heat pump is needed internally
- 4- Timers are set on the external thermostatic controller
- 5- Set heat pump a couple of degrees above the set point temperature of the external temperature controller.

- **Automation systems and additional controls**

The heat pump comes with easy to connect terminals in the electrical compartment labelled as 5 and 6.

The unit comes prewired with a bridge cable connected. To add an external control to activate the heat pump, remove the bridge and add in a volt free terminal connection. Please check with the automation system provider that the connection is volt free and the best way to install with their set-up.

If the external controller is not initiating the heat pump to operate the display will show the word "OFF"

D. Operation guidance

1. Key Function




Symbol	Heating & cooling models
	i. Power On/Off ii. Wi-Fi setting
	i. Lock/Unlock Screen ii. Heating mode (18-40°C) iii. Cooling mode (12-30°C) iv. Auto mode (12-40°C)
	i. Boost ii. Silence
	Temperature Setting



- a. Standby mode or Screen lock : Only symbol lights up, screen and other buttons turn darker.
- b. Power off mode : Only symbol will light up, No display on screen.
- c. The controller has a power-saving mode and will not display bright when locked.
- d. The controller has a built-in memory so all parameters are saved in the event of power loss

2. Operation Instruction

a. Screen Lock

- 1) Press  for 3 seconds to lock or unlock the screen
- 2) Automatic Lock Period: 30 seconds if no operation

b. Power On

Press  for 3 seconds to unlock screen, Press  to power on machine.

c. Temperature Setting

Press  and  to display and adjust set temperature.


d. Mode Selection

Heating/Cooling/Auto

Press  to switch between heating , cooling  and auto mode 

Heating mode : Water temperature setting range(18~40°C)




Cooling mode : Water temperature setting range(12~30°C)


Auto mode : Water temperature setting range(12~40°C)


* When water inlet temperature is higher than setting point, automatic cooling mode starts.

* When water inlet temperature is lower than setting point, automatic heating mode starts.


Silence/Boost mode selection


Press  to switch among boost mode , silence mode 

Default mode: boost 

Please choose boost mode  for initial heating

e. WIFI

When the screen is on, press  for 3 seconds, after  flashing, enter Wi-Fi connection.

Connect Wi-Fi on mobile phone and input password, and then control equipment by Wi-Fi. When APP connects Wi-Fi successfully,  lights on

PLEASE SEE WIFI OPERATION GUIDE FOR FURTHER INFORMATION

f. Defrost cycle



- Automatic active defrosting

When the machine is operating in low temperatures it is very common for ice to build up on the external coil. The heat pump has a built in defrost protection program which will activate when it senses ice starting to form.

When machine is defrosting, ☀ starts flashing; after defrosting ☀ is on continuously

- Forced defrosting,

If the heat pump requires manually defrosting for testing or a sensor is faulty please follow these instructions, the machine must be in heating mode and the compressor is working continuously for

more than ten minutes, Whilst the unit is running, press  and  on the

controller simultaneously and hold for 5 seconds. When the ☀ symbol is flashing, defrost has started, and will continue until the external coil temperature reaches a certain temperature adequate for continued operation. If the ☀ symbol stops flashing forced defrost has stopped.

*Note: the interval between forced defrosting should be more than 30 minutes apart.

E. Testing

1. Heat pump checks before use

- The air inlets and outlets are free of any debris and are not obstructed.
- Refrigeration pipes or components are not installed in a corrosive environment.
- Check electric wiring connections are tight and adhere to the electrical schematic
- Check for water leaks around the machine and all new water connections





2. Refrigerant leak detection

- Leak testing is prohibited in enclosed areas
- Any source of ignition is prohibited during leak checks.
- Leak detection fluids can be used with most refrigerants but the use of products containing chlorine should be avoided as the chlorine may react with the refrigerant and corrode the copper pipe.
- Vacuum the machine completely before welding. Welding should only be carried out by a professional person in a service center.
- Please stop immediately if a gas leak occurs, and contact your local service center.

3. Trial Run

- The circulation pump must start before the heat pump and stop after the heat pump to avoid any damage occurring to the machine.
- In order to protect the heat pump, the machine is equipped with a time lag start function, the fan will run 1 minute earlier than the compressor when starting the machine, and it will stop running 1 minute later than the compressor when power off the machine.
- After the heat pump starts, check for any abnormal noises from the machine.


4. Running status check

- Press and hold  for 5 seconds, a beep sound should be heard and it will enter into running status mode
- Use  and  to switch through the different values
- Press  again to quit can running status mode


Running status codes and corresponding values


Symbol	Content	Unit
C0	Inlet water temp	°C
C1	Outlet water temp	°C
C2	Ambient temp	°C
C3	Exhaust temp	°C
C4	Outer coil pipe temp	°C
C5	Gas return temp	°C
C6	Inner coil pipe tem	°C
C9	Radiator temp	°C
C10	Electronic expansion valve opening	P

. Parameters Checking

- 1.1 Press “

2. Modify parameters

- 2.1 In "parameter checking" status, press “

2.2 In "parameter setting" state, press “

3 Parameter Table

NO.	Content	Adjust range	Step length	Default
P0	Water pump running way	0 : Continuation 1 : Water temp control 2 : time/water temp control	1	2
P1	Time setting (only available when the water pump running way is set to “2”	10 ~ 120 min	5 min	60 min
P2	Compressor continuously running time in defrosting mode	30 ~ 90min	1min	35 min
P3	Defrosting start temp	-17 ~ 0℃	1℃	-7℃
P4	Defrosting running time	1 ~ 12min	1min	12 min
P5	Defrosting quit temp	8 ~ 30℃	1℃	13℃
P6	Single pump option	On/off 0 ~ 100	1	off
P10	Compressor speed control	0 : Auto, 1 : Manual	1	0
P12	Electronic expansion valve overheat level (heating)	-10 ~ 20	1	3
P13	Electronic expansion valve overheat level (cooling)	-10 ~ 20	1	5
P14	Electronic expansion valve manual/auto	0 : Auto, 1 : Manual	1	0
P15	Electronic expansion valve openning setting (heating)	50 ~ 240	2P	175 (H5)
P16	Electronic expansion valve openning setting (cooling)	50 ~ 240	2P	175 (H5)
P20	Power off memory function	0 — NO, 1 — YES	1	1

F. Commissioning

G. Commissioning

d. Flow Rates

OPTIMUM FLOW RATE DIFFERENTIAL FROM INLET TO OUTLET IS BETWEEN 2-3 DEGREES

Each Pool Heat Pump has a minimum flow rate requirement please check the specification table to ensure the circulation pump in use is adequately sized.

Calibrating the flow rate.

By using the running status function on the touch controller, it is easy to calibrate the check valves installed for optimum flow rates through the heat pump.

Madimack Heat Pumps have a built-in flow switch which will deactivate the heating function if not enough water flow is detected. The Heat Pump has a large range operation up to a seven-degree differential. If the temperature differential is above 7 degrees, the built-in flow switch or E6 Error will be displayed indicating not enough flow detected.

Recommended procedure

1. Open all isolating valves
2. Fully close the by-pass and switch the unit on to max temp.
3. Wait 3-4 minutes until heat pump is at 100% Capacity
4. Check inlet and outlet temperature through on-screen controller (Check "Running status check" in the previous section to obtain C0 and C1 values)
5. Open the by-pass valve to increase temperature differential (The difference between C0 and C1 values)
6. Close the by-pass valve to decrease temperature differential (The difference between C0 and C1 values)
7. Once optimum temperature difference (2-3 C) achieved lock position of by-pass if possible.

Checklist:

- ☐ Unit has been installed level
- ☐ Minimum ventilation requirements are correct to standards show in appendix K
- ☐ Condensation drain pipe has been connected and drains away from unit
- ☐ Rubber feet have been placed underneath unit
- ☐ Warranty registration details have been filled out in section L
- ☐ Temperature differential has been calibrated between 2-3


F. Maintenance



“Switch Off” power supply of the heater
before cleaning, examination and repairing

1. In winter season when you don't swim:
 - a. Cut off power supply to prevent any machine damage.
 - b. Drain water clear of the machine.

- c. Cover the machine body when not in use.



!!Important:

Unscrew the water nozzle of inlet pipe
to let the water flow out.

*When the water in machine freezes in winter
season, the titanium heat exchanger may be
damaged.*

2. Please clean this machine with household detergents or clean water, NEVER use gasoline, thinners or any similar fuel.
3. Check bolts, cables and connections regularly.
4. If repair or scrap is required, please contact authorized service center nearby.
5. Do not attempt to work on the equipment by yourself. Improper operation may cause danger.

G. Trouble shooting for common faults

1. Repairing Guidance



WARNING:

If repairs or removal is required, contact authorized service center.

Requirements for Service Personnel

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Do not attempt to work on the equipment by yourself. Improper operation may cause danger.
- Strictly comply with the manufacturer's requirements when charging R32 gas and equipment maintenance. This chapter focuses on special maintenance requirements for swimming pool heat pump with R32 gas. Please refer to the technical service manual for detailed maintenance operation.
- Vacuum system completely before welding. Welding should only be carried out by professional person in a service center.

2. Problems without an error code

Failure	Reason	Solution
Heat pump doesn't run	No power	Wait until the power recovers
	Power switch is off	Switch on the power
	Fuse is broken	Check and change the fuse
	The breaker is off	Check and turn on the breaker
Fan running but with insufficient heating	Evaporator blocked	Remove the obstacles
	Air outlet blocked	Remove the obstacles
	3-minute start delay	Wait patiently
Display normal, but no heating	Set temperature too low	Set proper heating temp.
	3-minute start delay	Wait patiently
If above solutions don't work, please contact your installer with detailed information and your model number. Please don't try to repair it yourself.		

Note: If the unit frequently trips the circuit breaker, please stop the machine immediately by switching off the main power and contact your dealer or local repair centre.


Protection & Failure code

Error	Component corresponding	What did the error detect?	Solution
E1	High pressure protection	High gas pressure switch	1. Check the water flow from the filtration pump and ventilation clearances. 2. Check high pressure switch is closed circuit 3. Replace PCB 4. replace inverter board
E2	Low pressure protection	Low gas pressure switch	1. Check the water flow from the filtration pump and ventilation clearances. 2. Check low pressure switch is open circuit 3. Replace PCB 4. replace inverter board
E3	No water protection	Low water flowrate	Check the water flow in pipes, and filtration pump is running. Check filters, skimmer basket, back wash Check the bypass or valves have not been adjusted since commissioned Check the Water flow switch
E4	3 phases sequence protection	Electrical power connection	Check the power connection to the pump
E5	Power supply excesses operation range (Not failure)		1). Recover when back to the normal power 2). Replace PCB
E6	Excessive temp difference between inlet and outlet water (Insufficient waterflow protection)	High temperature difference	Check the water flow in pipes, and filtration pump is running. Check the bypass is opened and unit is commissioned Check the Water flow switch
E7	Water outlet temp too high or too low protection	Water flowrate in pipes	Check if there is any blockage in the inlets, outlets, and through the pipe
E8	High exhaust temp protection	Compressor overheating	Check if refrigerant gas is leaking, check the connection of the sensor, might need to change if faulty, check the compressor of the pump
Eb	Ambient temperature too high or too low protection (not failure)	Out of the heat pump's capacity to withdraw heat from the atmosphere	Out of application range
Ed	Anti-freezing reminder (not failure)		Wait for automatic recovery
F1	Compressor drive module failure	Lack of phase	Check the voltage and the frequency conversion
F2	PFC module failure	PFC circuit	Check the PFC switch circuit if short or not
F3	Compressor start failure	Compressor circuit	Check the compressor wiring if its correct or if there is any short circuit
F4	Compressor running failure	Compressor circuit	Check the compressor wiring if its correct or if there is any short circuit
F5	Inverter board over current protection		1). Wiring 2). Inverter board 3). PCB
F6	Inverter board overheat protection	Inverter board high temp	Check the current flowing it might need to

F7	Current protection		1). Power off and restart 2). Inverter board 3). Compressor
F8	Cooling plate overheat protection		1). Power off and restart 2). Check fan motor 3). Check cooling plate
F9	Fan motor failure	Fan motor	Check the fan motor wiring, check if the fan is broken or loose
Fb	Power filter plate No-power protection	Power filter not working	Single Phase Model 1). Replace Inverter board 3 Phases Model 1). Replace power filter plate
FA	PFC module over current protection	Solar inverter voltage change Power black out Power surge	1). Initial power testing has completed. Power off and restart (happens install with solar PV) 2). Replace Inverter board
P1	Water inlet temp sensor failure	The water inlet temperature sensor is either damaged or running a short circuit	Check the Temperature sensor at the water inlet, might need to be changed
P2	Water outlet temp sensor failure	The water outlet temperature sensor is either damaged or running a short circuit	Check the Temperature sensor at the water outlet, might need to be changed
P3	Gas exhaust temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Check the gas exhaust Temperature sensor, might need a replacement
P4	Evaporator coil pipe temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Check the evaporative coil pipe Temperature sensor, might need a replacement
P5	Gas return temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Check the Gas return Temperature sensor, might need a replacement
P6	Cooling coil pipe temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Check the cooling coil pipe Temperature sensor, might need a replacement
P7	Ambient temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Check the Ambient Temperature sensor, might need a replacement
P8	Cooling plate temp sensor failure	The sensor is running a short circuit, damaged, or not fixed properly	Replace inverter board
P9	Current sensor failure	The sensor is running a short circuit, damaged	1). Replace inverter board for single phase model 2). Replace power filter plate for 3 phases model

H. Electrical wiring schematic

Water pump: 400V voltage



Water Testing Pump Output

For an individual pump system only used for pool heating.

The heat pump is fitted with a smart controller output which allows water testing to occur after a set period of time after the heat pump has reached temperature. This can be activated through the internal settings but is not set as default.

E.G the pump runs every hour for 3 minutes to test the water temperature, if the temperature is below set point the pump will continue to run and heat the pool, when the temperature is achieved the heat pump and pump will switch off and testing time will begin again.

For further information please contact your sales representative.

External input

Some units come with a built-in external input labelled 5 and 6. This comes standard as a looped connection and is used for an external signal.

This is a volt free contact and with continuity through connections 5 and 6 it will signal the unit to operate. Note. It will only activate if the timers are activated in parallel with the input.


This external input allows the system to run with most automation systems or in combination with solar systems where there is a priority heat source.

For more information please contact your local sales representative or contact technical sales


I. Wi-Fi operation

For video tutorials and further help please visit www.Madimack.com.au FAQ for all you need to do and full walkthrough. It is crucial that the WiFi is over the machine and is of a high power, the WiFi is a cloud based solution and needs the WiFi to be active on the machine for it to receive a signal.


① APP Download



Android please download from




iOS please download from






② Account Registration

1. Register by mobile or E-mail.




2. Mobile or E-mail registration.



3 Create Family

Please set family name and choose the room of device.




4 APP Pairing





Please make sure you are connected to the Wi-Fi.

1. Press “ M” for 3 seconds to unlock the screen, press “ ” for 3 seconds then release, after hearing “Beep”, enter Wi-Fi password in APP. During connection, “ ” flashes, when the APP connects to the Wi-Fi successfully, “ ” will display.



2. Click "Add Device", and then follow instructions to pair device.





5 Operation

1. For heat pump with Heating function only :




2. For heat pump with Heating&Cooling function :



6 Share Devices to Your Family Members

After pairing, if your family members also want to control the device.
Please let your family members register the APP first, and then the administrator
can operate as below:



Notice:

1. The weather forecast is just for reference.
2. App is subject to updating without notice.

Heat Pump Warranty Agreement

This Warranty applies to domestic and commercial products purchased and installed in Australia.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Your Australian Consumer Law guarantees, and similar statutory rights, are called the “Owner’s Statutory Rights” in this Warranty.

THE RIGHTS GIVEN BY MADIMACK AUSTRALIA 2 YEARS WARRANTY ARE IN ADDITION TO THE OWNER’S STATUTORY RIGHTS.

The Madimack [Pty Ltd \("Madimack"\)](#) equipment listed on the back of this card is warranted by Madimack against defects in design, materials and workmanship for a period of up to 2 Years from the date the equipment is purchased by the original owner.

Equipment defects covered by this Warranty will be repaired or replaced at the discretion of Madimack (subject to the Owner's rights under the Australian Consumer Law with respect to major failures) without cost to the owner for parts or direct repair labour. The repair or replacement shall be performed during normal business hours by Madimack or a repair agent authorised by Madimack.

Any Madimack parts or Madimack equipment replaced under this Warranty will be warranted in accordance with the provisions of this Warranty for the remainder of the original warranty period or 12 months from the completion of the repair, whichever is the greater. Except where inconsistent with the Owner's Statutory Rights and the rights given by this Warranty, all other warranties and all liability of Madimack for any loss or damage direct and consequential is expressly excluded.

This Warranty DOES NOT cover: -

- a) Damage or problems or unsatisfactory performance caused to the equipment by faulty or incorrect external electrical wiring, incorrect power supply, voltage fluctuations, over voltage transients or electromagnetic interference not originating within the equipment.
- b) Damage or problems resulting from incorrect or poor installation.
- c) Damage or problems caused by the use of an accessory, component or equipment not supplied by Madimack.
- d) Damage or problems caused by storm, fire, flood, vandalism, misuse, negligence, Acts of God, earthquake, war, vermin, foreign matter entering the equipment (e.g. dirt and moisture) or any other outside agency.
- e) Damage or deterioration to the external surfaces or refrigeration coils caused by normal weathering or corrosive atmospheric conditions.
- f) Any costs or additional labor associated with gaining acceptable service access to equipment installed in restricted or unsafe (e.g. high) locations.
- g) Freight charges (including insurance) or travelling cost for repairs performed outside the area normally serviced by Madimack or a repair agent authorized by Madimack.
- h) Equipment which has been installed in a transportable or mobile application (e.g. caravan or boat).
- i) Equipment which has been re-installed in a transportable or mobile application (e.g. caravan or boat).
- j) Equipment which has been re-installed at a location other than the original location.
- k) Any consumable item (e.g. batteries, filters, and belts) supplied with the equipment unless the item is shown to be defective at the time of purchase.
- l) Damage or problems or unsatisfactory performance resulting from operation in an environment where the climatic comfort of humans is not the primary function of the equipment.
- m) Damage or problems or unsatisfactory performance resulting from operations at conditions outside the operating conditions specified in the Madimack technical or sales literature applicable to the equipment.
- n) Damage, problems or unsatisfactory performance resulting from misapplication of the equipment.

Where this Warranty does not apply, the Owner's rights are limited to the Owner's non-excludable Statutory Rights.

Owner's Responsibility

The owner is responsible for the correct operation and regular maintenance of the equipment as listed below. The correction of any non-product fault or problem is not covered by this warranty.

- a) Operation and maintenance of the equipment in accordance with the operating instructions.
- b) Regular cleaning of the air filter(s) and replacement where necessary.
- c) Ensuring that the air inlet and outlet on the outdoor unit is kept clear of any obstructions (e.g. dirt, leaves, plants)
- d) Ensuring that the condensate drain is kept clean.
- e) Replacement of exhausted batteries.
- f) The application of additional corrosion protection if the product is installed in a corrosive environment (e.g. Industrial pollution, sea air).

Owner's Statutory Rights

In respect of any goods supplied under the contract which are not of a kind ordinarily acquired for personal domestic or household use or consumption, unless the owner establishes the following limitation of liability would not be fair and reasonable, the liability of Madimack for any defect of design, materials or workmanship will be limited to any of the following as determined by Madimack: -

- a) Replacing the equipment or supplying equivalent equipment;
- b) Repairing the equipment;
- c) Paying the cost of replacing the equipment or acquiring equivalent equipment;
- d) Paying the cost of having the equipment repaired.

Making a claim

The following steps should be taken when making a warranty claim with Madimack Pty Ltd.

1. Owners experiencing issues with their system are to contact Madimack Pty Ltd service departments online portal to and provide the requested information.
2. A service agent will review the provided information and will contact you on the provided phone number to try and solve the issue
3. If the issue cannot be dealt with over the phone, owners will be supplied with details of service agent in their area
4. Owners will need to contact and deal with service agents directly in relation to the booking in and payments of works related to the service or repair of their Madimack Pool Heat Pump
5. Owners can claim reimbursement for costs of works covered under the product warranty when completed by an approved Madimack Service Agent. When making a claim, owners will need to provide the following documents
 - a) Proof that you are the original system owner – original invoice showing owner name and property address
 - b) Copy of invoice from an approved Madimack approved service agent
 - c) For a major defect a copy of the report for major defects from approved Madimack Service agent
 - d) All Service Claim Submissions will be processed and reimbursement on validated claims paid into owner nominated account within 7 business days.

Product Warranty Registration

Please complete all the details below from the installer and store card along with the purchase docket in a safe place.

Please take 2 or 3 photos of the installation and with this information upload them online at

<https://www.madimack.com.au/warranty-registration>

or use the barcode scanner to go direct to the page.



this

Supplied by	
Date of Purchase	
Installed by	
Installer No (if applicable)	
Date of Install	
Owners full name	
Address of Premises	
Telephone number	

Make	
Model	
Serial	
Commissioning	
By pass valve fitted?	
Temperature difference	
Notes	

Warranty Period

Pool Heat Pump	Warranty		
Series	Parts	Labour	Titanium Exchanger
EM 60/110	2	1	5 Years

IMPORTANT NOTE For repair of equipment under this Warranty it is recommended that the owner contact their Madimack Dealer / Installer. If the owner requests Madimack to perform or arrange the service call, the owner will be liable for all associated costs if the problem is not covered by the provisions of this Warranty or the Owner's Statutory Rights. For warranty claims please see [Madimack.com.au](https://www.madimack.com.au) and check the technical and service section including the FAQ provided if problems are still present please fill out the online form for attention and one of our service representatives will be in touch.