BAR MOUNT 1.5" OD BAR RAIL BRACKET



AVAILABLE FINISHES











BRUSHED STAINLESS

BRUSHED BRASS

POLISHED BRASS

OIL RUBBED **BRONZE**

MATTE **BLACK**

SPECIAL ORDER FINISHES











STAINLESS GREY

ANTIQUE BRASS

SUNSET **COPPER**

CUSTOM COLORS ARE AVAILABLE BY REQUEST

W CP₁

DIMENSIONS

(W)	WIDTH	7.23"
(H)	HEIGHT	6.11"
(D)	DIAMETER	1.50"
(CP₁)	CENTER POINT 1	6.38"
(CP ₂)	CENTER POINT 2	5.24"

INCLUDES

3 x #10 1-1/2" Mounting Screws

1 x #8 3/4" Self-Drilling Set Screw

Nut & Bolt Assembly:

1 x Bolt - Fully threaded, 5/16" - 18 x 3"

1 x Hex Nut - 5/16" - 18

1 x USS Flat Washer - 5/16"

INSTALLATION

Bar mount brackets include a nut and bolt assembly to properly support the weight. To ensure adequate support, a solid backing at least 3/4" deep is required.

- 1. Measure & mark holes for mounting screws and for the threaded bolt.
- 2. Drill hole in bar diewall for the threaded rod.
- 3. Attach bracket from behind bar face using rod and secure with bolt and washer.
- 4. Attach brackets to the face of the bar with the 3 mounting screws.
- 5. Secure tubing to bracket by fastening set screws through hole in the bottom of bracket.

Care and maintenance of bar foot rail varies by finish. Given the nature of the product, typical wear and tear may be noticed with your bar rail over time, such as scuffs, scratches, and dirt. Visit kegworks.com/bar-rail-care to read our guide on how to properly prep, clean & maintain all bar rail finishes.