



DL-18


The DL-18 is the most powerful piece of hardware you can have on any paint truck. Choose the widgets you need for the job. Monitor your operation in real-time and set your targets with LLAMA. Customize your view for each job with the DL-18 interface, keeping your eyes on the data most important to you.

DESIGNED FOR AN INTUITIVE USER EXPERIENCE!


Environmental Conditions



Beads



Set Targets with LLAMA



Target Zero Waste
Use Advanced Controls (LLAMA)



Integrated Data Logging
Meet Demanding Job Specs



Everything You Need
Handles All Material Types



Real Time Monitoring
Key Job Information at a Glance



UPGRADE TO THE ULTIMATE STRIPING EXPERIENCE!



(541) 963-0111



10514 N. McAlister Road
La Grande, OR 97850




sales@skipline.com



www.skipline.com

UNLOCK THE POWER OF SPEC-RITE ONLINE

Access every facet of Spec-Rite Online with the **Precision Suite** subscription: data logging, web reporting, training, and an extended warranty on hardware.



ALL THE DATA YOU NEED

Stay in control of your striping operation with the DL-18, your truck's command center. Enable data logging on your truck, giving you the keys to the most powerful tools on the market.

The LLAMA is the ultimate add-on to the DL-18, bringing more control to your fingertips. Track your striping operation closer than ever before, ensuring you meet job specifications and keep material costs down.



SKIP-LINE LINE PILOT XP

ADJUST CROSS HAIR LINES ON THE FLY



The Skip-Line Line Pilot XP makes it easy to adjust and fine-tune cross hair lines on the DL-18 while driving. Operators can use toggles to adjust on-screen line positioning. Adjust location, tilt, and thickness of existing cross hair lines on the DL-18 display.

Functionality

- ① Move Left/Right
- ② Move Up/Down
- ③ Increase/Decrease Line Width
- ④ Rotate Clockwise/Counterclockwise
- ⑤ Line Select (scroll through the available lines)