

HOW TO:

Operate a Box Blade on a CAT Skid Steer

1. Once inside the skid steer, ensure that:
 - a. Door is closed
 - b. Seat belt is fastened
 - c. Arms are down
2. Above and to the right, verify that the Hydraulic lockout is disengaged and that hydraulics are activated:





3. Above and to the left, engage Aux 8 and turn off Aux 7 (Rabbit):



4. To allow for Autos, hold the roller forward on the right-hand joystick until the Hydraulics icon changes from flashing to steady on the machine display.

See reverse side for further instructions



Button	Function in Manual Mode	Function in Automatic Mode
3	Lower – Machine Right Side	Decrement – Machine Right Side
4	Raise – Machine Right Side	Increment – Machine Right Side
5	Lower – Machine Left Side	Decrement – Machine Left Side
6	Raise – Machine Left Side	Increment – Machine Left Side
7	Engage Automatic	Return to Manual