



A B C D E F G H I J K L

M N O P Q R S T

U V W X Y Z

APPLICATION INSTRUCTIONS FOR THE

UPPER CASE LETTER SET

Product Number: 11-SP-030

SIZE: each letter approximately 10 inches high.

ESTIMATED PAINT TIME: depends on desired pattern.

FIRST READ: Completely read "General Instructions".
Prepare surfaces as recommended before painting.

1. Stencils are individual squares. Align as desired, noting the widths vary. Using small brushes, paint each stencil as desired.
2. Repeat 1-2 more times to achieve desired vividness, drying after each application, and remove stencil.
3. Allow to dry for 24 hours before use.

Any questions? We're here to help – call us at (800) 681-0684!



THIS INFORMATION IS COPYRIGHT MATERIAL. ALL RIGHTS ARE RESERVED.

© 2017 FIT AND FUN PLAYSCAPES, LLC