


Thank you for purchasing this fine quality "Made in America" product. When properly assembled and installed, your racking will complement your wine collection for many years to come. To ensure proper assembly, please make sure that all necessary parts have been included and follow instructions closely.

If you have questions or problems please call us at 845-658-7181, Monday through Friday between 9am & 6pm EST

Parts & Tools



If you are planning to stain or finish your racking, we recommend you do so BEFORE assembly for best results



This rack is designed to be assembled with a nail gun, using either 18 gauge 1 1/2" brad nails or similar finishing nails. Nails are not included.*

Instructions show a sample 6 column rack. All 38 1/4" Upper Racks are assembled in the same manner. Your order will contain the specific number of ladders and spacer bars appropriate for your chosen rack. Racks wider than 10 columns will have segmented spacer bars with clips to attach them together.

**** If you purchased pre-drilled screw assembly you would have received pre-drilled spacer bars and 1 1/2" Phillips head screws as part of your order***





Package Contents

SKU	PRODUCT NAME	MIDDLE LADDERS	END LADDERS	SPACER BARS	*SCREWS (if used)
8_3-000-0525-3825-X	1 Col. 38 1/4" Upper w/display row	0	2	4	8
8_3-000-0975-3825-X	2 Col. 38 1/4" Upper w/display row	1	2	4	12
8_3-000-1425-3825-X	3 Col. 38 1/4" Upper w/display row	2	2	4	16
8_3-000-1875-3825-X	4 Col. 38 1/4" Upper w/display row	3	2	4	20
8_3-000-2325-3825-X	5 Col. 38 1/4" Upper w/display row	4	2	4	24
8_3-000-2775-3825-X	6 Col. 38 1/4" Upper w/display row	5	2	4	28
8_3-000-3225-3825-X	7 Col. 38 1/4" Upper w/display row	6	2	4	32
8_3-000-3675-3825-X	8 Col. 38 1/4" Upper w/display row	7	2	4	36
8_3-000-4125-3825-X	9 Col. 38 1/4" Upper w/display row	8	2	4	40
8_3-000-4575-3825-X	10 Col. 38 1/4" Upper w/display row	9	2	4	44
8_3-000-5025-3825-X	11 Col. 38 1/4" Upper w/display row	10	2	4	48
8_3-000-5475-3825-X	12 Col. 38 1/4" Upper w/display row	11	2	4	52
8_3-000-5925-3825-X	13 Col. 38 1/4" Upper w/display row	12	2	4	56
8_3-000-6375-3825-X	14 Col. 38 1/4" Upper w/display row	13	2	4	60
8_3-000-6825-3825-X	15 Col. 38 1/4" Upper w/display row	14	2	4	64
8_3-000-7275-3825-X	16 Col. 38 1/4" Upper w/display row	15	2	4	68
8_3-000-7725-3825-X	17 Col. 38 1/4" Upper w/display row	16	2	4	72

Assembly Instructions

PLEASE VERIFY YOU HAVE THE CORRECT NUMBER OF PARTS BEFORE PROCEEDING
FOLLOW WRITTEN INSTRUCTIONS CAREFULLY

1. Find an open, flat area in which to assemble your racking. Carefully remove all components from the box and check all parts to verify package contents.
2. Beginning with the BACK of the rack. Arrange the End Ladders with the bottle supports facing the inside of the rack. Attach a spacer bar to the top of the rack and at the last bottle support on the bottom of the rack.
3. Fill in the middle of the rack by attaching the Middle Ladders to the spacer bars. Make sure that the display angle is facing the correct direction.
4. Flip the rack over and attach the spacer bars to the top and very bottom of the rack.



If using rack on top of a base you can nail through the bottom spacer bar of the upper rack into the top spacer bar of an assembled base rack. It is recommended you secure both racks to a wall for optimal stability. Hardware for attaching to a wall is not supplied. Simple "L" brackets from your local hardware store are a popular option for securing to a wall.