




Model: RT-16 Data Sheet



: YUhi fYg

7 cblfc`g

Basic Movement A Ξ / [\dot{q} [\dot{q} \dot

 $\acute{U}_{l}^{\prime} \wedge \bullet \wedge o \acute{U}_{l}^{\prime} \bullet \tilde{a} \tilde{a}_{l}^{\prime} \} \bullet / \tilde{E}_{0}^{\prime} \\ \text{Once in the desired position, press the 'M' button followed by a number.}$

Locking - Press and hold the 'M' button until the menu appears. Navigate to the 'Lock' icon and press 'M' to activate. It will take 10 seconds for lock to activate.

Unlocking - Once the lock is activated, press '1', '2', '3' to temporarily unlock the remote for adjustments. After 10 secs of being idle the remote will lock again. To turn the lock mode off, press and hold the 'M' button until the menu appears. Navigate to the "Lock" icon and press 'M' to deactivate. The unlocking symbol will appear.

Ù^å^} cæf Á理录{ - Press and hold the 'M' button until the menu appears. Navigate to the 'Bell' icon and press 'M' to activate. The user can select between '30', '40', '50', or '60' minute time intervals for the alarm to vibrate.

W]] $^{\dot{}}$ $^{\dot{}$