

Clorox Healthcare® Cleaner Disinfectants. Use on durable coated fabrics from the Mitchell Group.



Mitchell is a manufacturer of Sta-Kleen® Performance coated fabric upholstery — polyurethane and silicone — that are used in a range of commercial applications, including healthcare settings.

Following testing for compatibility, two Clorox Healthcare® cleaner disinfectants are approved to clean and disinfect Sta-Kleen® Polycarbonate and Sta-Kleen® Silicone coated fabrics, with no rinsing and drying of the fabric required after application of the cleaner disinfectant.

Mitchell sta*kleen® Brands



Sta-Kleen Polycarbonate (PC) is a polyurethane coated upholstery fabric made from a 100% polycarbonate resin system. The polycarbonate resins provide for an incredibly strong and durable product. Sta-Kleen PC is engineered to perform in the most demanding commercial environments. To do so, requires that it has performance values that are greater than the current standards set by the Association of Contract Textiles (ACT) for regular commercial applications. The combination of the polycarbonate resins and Sta-Kleen stain resistance means Sta-Kleen PC can withstand the harsh chemical disinfectants used in commercial environments such as hospitals, nursing homes and schools.

Patterns: Butte, Donegal, Galaxy, Matrix, Natural, Paris, Pyramid, Sammie, Saw Cut, Sparkle.



Sta-Kleen Silicone is the newest innovation in the Sta-Kleen family of coated fabrics made from 100% silicone with a 100% polyester knit backing. The manufacturing process does not use any solvents and very little water or energy. There is no VOC released, no organic pollutants and no toxic by-products. Sta-Kleen Silicone has been accepted into the Healthier Hospitals Initiative and is eligible for LEED interior building materials credits.

Patterns: Hayden, Santa Fe, Silex.

Clorox Healthcare® Products



Clorox Healthcare® VersaSure® Cleaner Disinfectant Wipes

An alcohol-free quat wipe with 2-minute kill times, low odor and low residue.

Clorox Healthcare® Hydrogen Peroxide Cleaner Disinfectants

With broad surface compatibility, low residue, and a 1-minute contact time, these cleaner disinfectant wipes and liquids are designed for use on common hospital surfaces.

How to use these products on Sta-Kleen Polycarbonate and Sta-Kleen Silicone

1. Remove visible soil such as dirt and organic material.
2. Apply the disinfectant following the directions for use on the product label. Ensure that the surface stays wet for the contact time listed on the product label.
3. Allow the surface to dry, or wipe.

Tips for Use:

If you want the fabric to look its best and to reduce potential for damage, wipe periodically with a damp cloth to remove disinfectant residue.

If the fabric is scratched, torn, or damaged, rinse and dry the surface after application of the disinfectant.

Where can products be used?

Furnishings in all healthcare settings: hospital, outpatient, Ambulatory Surgical Centers, physician offices, dental offices.

Who can use these fabrics?

Designers, architects, healthcare and dental furniture manufacturers, hospital planners and specifiers.

Disclaimer: The Mitchell Group® and Clorox Healthcare® are not responsible for any defect caused by use of cleaning and disinfecting solutions not included in this guide and which are used without rinsing or drying after application. If you are using products other than Clorox Healthcare® VersaSure® Cleaner Disinfectant Wipes or Clorox Healthcare® Hydrogen Peroxide Cleaner Disinfectant Wipes, please consult the cleaning and care guidelines for these Sta-Kleen brands at <https://mitchellfauxleathers.com/>.

Clorox Healthcare
For product information and implementation tools, contact your Clorox sales representative or call 800-234-7700
Visit: www.CloroxHealthcare.com
Email: healthcare@clorox.com
© 2020 Clorox Professional Products Company
1221 Broadway, Oakland, CA 94612

The Mitchell Group
7040 N. Austin Ave., Niles, IL 60714
Customer Service: (877) 647-7301
Corporate Main: (847) 647-7300
Fax: (847) 647-7337
Visit: www.Mitchellfauxleathers.com
Email: info@mitchellfauxleathers.com
© 2020 The Mitchell Group